


## Guidelines on choosing the size of a sling

### ABC Slings

All dimensions in cm



| Size / cm  | W1      | W2 <sup>x)</sup> | W2 <sup>xx)</sup> | H        |
|------------|---------|------------------|-------------------|----------|
| Kids 2-4   |         |                  | 46 - 54           |          |
| Kids 4-6   | 25 - 30 | 50 - 90          | 50 - 65           | 45 - 60  |
| Kids 6-10  | 28 - 33 | 60 - 95          | 51 - 72           | 55 - 70  |
| Kids 10-14 | 31 - 36 | 65 - 100         |                   | 68 - 80  |
| Kids 10-16 |         |                  | 56 - 75           |          |
| XS         | 33 - 37 | 70 - 105         |                   | 75 - 82  |
| S          | 36 - 40 | 75 - 110         |                   | 80 - 87  |
| M          | 39 - 43 | 80 - 120         |                   | 85 - 92  |
| L          | 42 - 45 | 90 - 130         |                   | 90 - 97  |
| XL         | 45 - 49 | 100 - 140        |                   | 95 - 102 |
| 2XL        | 48 - 54 | 110 - 150        |                   | 95 - 102 |
| 3XL        | 54 - 58 |                  |                   | 95 - 102 |
| 4XL        | 57 - 63 |                  |                   | 95 - 102 |
| 5XL        | 62 - 73 |                  |                   | 95 - 102 |

#### **W2 = Chest measurements**

x) Guideline for choosing Active Trainer and Gait Trainer

xx) Guideline for choosing Active Vest Kids